

Minimizing self-service touchscreen interactions

Configuration options for Liber8

Put Liber8 in check-out mode:

Result: Liber8 will automatically open the login screen.

Go to: Admin Menu > Function Administration > Main Screen Functions

Select:

- | 1 for Borrow Items
- | 0 for Account
- | 0 for Return Items

Save your changes.

Issues with this mode of operation: Payment, Account and Renewal buttons can't be chosen from the main screen. Users with a PIN will still have to touch the screen to enter their PIN.

Put Liber8 in check-in mode:

Result: Liber8 will automatically open on return screen.

Admin Menu > Function Administration > Main Screen Functions

Select:

- | 0 for Borrow Items
- | 0 for Account
- | 1 for Return Items

Save your changes.

Issues with this mode of operation: Payment, Account and Renewal buttons can't be chosen.

Reduce the default timeout on the check-out/in screens:

C:\Program Files\Bibliotheca\Liber8\SelfCheck.ini

[OPTIONS] section

Timeout Seconds = 20 (You may adjust the number of seconds to suit your users).

Print a receipt automatically after each transaction:

C:\Program Files\Bibliotheca\Liber8\SelfCheck.ini

[RECEIPT PRINTER] section

PrintLevelBorrow = 1

PrintLevelReturn = 1

PrintLevelRenew = 1

PrintLevelStatus = 1

You can access liber8 admin mode by scanning admin card or or typing you admin code on patron login screen.